
# AE 4610 – Lab 3 data

- a. Initial Roll gains Kd = 25.4594, Kp = 29.3417
   b. Initial Pitch gains Kd = 33.4062, Kp = 35.3998, Ki = 0.3540
   c. Initial yaw rate controller gains Kp = 1.4853, Ki = 0.0149
- 2. Isolated Roll, Pitch, & Yaw Rate simulink models and step responses, with both the plot and a capture of the information provided by the "stepinfo" Matlab function. For the report, you need only include the relevant stepinfo information (e.g. peak time/rise time, settling time)


#### Roll:




RiseTime: 1.4071
TransientTime: 4.2285
SettlingTime: 4.2285
SettlingMin: 0.3165
SettlingMax: 0.3934
Overshoot: 11.8782


Undershoot: 0

Peak: 0.3934
PeakTime: 3.0300



## Pitch:






RiseTime: 0.6650
TransientTime: 1.7841
SettlingTime: 1.7841
SettlingMin: 0.1574
SettlingMax: 0.1885
Overshoot: 8.0200

Undershoot: 0


Peak: 0.1885
PeakTime: 1.4000

#### Yaw:




RiseTime: 4.0773
TransientTime: 5.4921
SettlingTime: 5.4921
SettlingMin: 0.1591
SettlingMax: 0.1767
Overshoot: 0
Undershoot: 0

Peak: 0.1767
PeakTime: 9.9800




3. Combined nonlinear Simulink model, with the Yaw Rate step response validated with both a plot and "stepinfo" information





RiseTime: 2.3128
TransientTime: 4.7433
SettlingTime: 4.7433
SettlingMin: 0.9075
SettlingMax: 1.0182
Overshoot: 1.0224
Undershoot: 0

Peak: 1.0182 PeakTime: 16.1900





- 4. a. Final Roll gains Kd = 12.7297, Kp = 29.3417
  b. Final Pitch gains Kd = 31.7350, Kp = 35.3998, Ki = 0.3540
  c. Final yaw rate controller gains Kp = 1.0397, Ki = 0.0104
- 5. Pitch, Yaw Rate, and Yaw attitude plots for the case of Pitch command of 0 degrees





6. Pitch, Yaw Rate, and Yaw attitude plots for the case of Pitch command of 20 degrees





- 7. The length of time required for the 3DOF helicopter to rotate 180 degrees for each pitch command (list each time separately, even if you find the time to be the same)
  - a. 18s
  - b. 18s